

# Usage Guide

## Can be installed over:

	Wood Products	CBU	Mortar Bed
Fracture-Guard 5000	X <sup>1</sup>	X	X
Hydro-Guard 2000		X	X
Hydro-Guard One		X	X
BFP		X	X
Urethane	X <sup>1</sup>	X	X

## Can be used as a positive waterproof membrane:

Hydro-Guard 2000	X <sup>2</sup>	X	X
Hydro-Guard One	X <sup>2</sup>	X	X
BFP	X <sup>2</sup>	X	X
Urethane	X <sup>2</sup>	X	X

NOTE: When using a cast iron sub-drain, caulk between top and bottom sections.  
When using a PVC sub-drain do not caulk between top and bottom sections.

## Setting Tile Guide – Use this guide to set:

Thin Set Adhesives	Porcelain	Ceramic	Marble	Granite	Glass	Travertine	Quarry	Saltillo
200/211	X	X	X	X	X	X	X	X
700		X				X	X	X
705		X	X	X	X	X	X	X
710		X	X			X	X	X
720		X	X	X		X	X	X
735	X	X	X	X	X	X	X	X
740	X	X	X	X	X	X	X	X
750		X	X	X	X	X	X	X
801*	X	X	X	X	X	X	X	X
626 Primer**								

801\* – Use only 801 thin set when setting impervious tile (i.e. porcelain) to an impervious material.  
(i.e. Fracture-Guard 5000 or any waterproof membrane)

626 Primer\*\* – Use 626 Primer prior to setting tile products when the substrate is questionable.

## Use this guide to set to:

Thin Set Adhesives	Concrete Surfaces	Exterior Grade Wood Products	CBU	Interior	Exterior <sup>1</sup>	Gypsum Products <sup>1</sup>
200/211	X	X	X	X	X	X
700	X		X	X	X	X
705	X	X	X	X	X	X
710	X		X	X	X	X
720	X		X	X	X	X
735	X	X	X	X	X	X
740	X	X	X	X	X	X
750	X		X	X	X	X
801*	X	X	X	X	X	X

x = Yes

<sup>1</sup> – Dry areas only

<sup>2</sup> – Call manufacturer for specifications



**MER-KRETE SYSTEMS**  
**(800) 851-6303**

Mer-Krete Systems  
501 Van Ness Avenue  
Torrance, California 90501  
A Division of ParexLahabra

Tel: (323) 775-2461  
Fax: (310) 320-4938  
Internet: [www.merkrete.com](http://www.merkrete.com)  
E-mail: [info@merkrete.com](mailto:info@merkrete.com)

REV 6/07

For the latest and most current product information, make sure to visit our website at: [www.merkrete.com](http://www.merkrete.com)