



## Installing WindowWrap™-Flex

1. Cut strip of WindowWrap-Flex about 6" - 10" wider than the window opening. Remove protective backing and install so that the material covers the sill area where the window will be and flows up each jamb at least 3".



2. Smooth WindowWrap-Flex into the window sill opening with your hands.



3. Fold WindowWrap-Flex down the face of the outer wall and press into place with your hands. If necessary, you may add a staple to each corner to prevent movement.



4. Roll entire surface with a hand roller to ensure good adhesion. The photo at the right shows the entire sill covered with WindowWrap-Flex, but all you really need is to cover the area where the window will be installed.



5. Finish by installing the window, and taping the sides and header. The installation at the right shows WindowWrap-Butyl installed on the side jambs and header. Note that the header tape is correctly installed underneath the house wrap directly to the sheathing to prevent water from being channeled into the window opening.

