



## **KWANG SUNG CO., LTD**

**1-55 WEOLAM-DONG, DALSEO-GU, DAEGU, KOREA**

**TEL: 82-53-582-1177**

**FAX: 82-53-582-1178**

### **UFP WRAP RECOMMENDED NAIL PATTERN**

Kwang Sung Co., LTD. and more specifically, UFP Wrap, has provided nailing/installation instructions that are intended to meet ICC regulations for installation of our home wrap during on site building. In a controlled environment and with the absence of ICC restrictions please feel free to install the home wrap to your specific industry standards.

The definitive rationale is to securely fasten the UFP Wrap home wrap in a manner that promotes a secure hold until the final cladding is in place. Subsequently the installation of the final cladding should also contribute to the hold of the UFP Wrap home wrap.

We also recommend the use of UFP home wrap seaming tape, or equivalent seaming tape, to additionally secure the seams in a manner consistent with local and/or required federal building codes.