



525 Orange Street
P.O. Box 340
Coshocton, Ohio
43812

800-882-7663
740-622-2645
fax: 740-622-6161
www.mfmbp.com

SEPTEMBER 29, 2010

Subject: Rolled shingle starter application for Manufactured Housing

This letter is to inform you that MFM finds it acceptable to install the 7.2" rolled shingle starter in the following manner for manufactured housing. In fact, we feel this installation method will both assure proper performance, and maximize the value of the complete seal the underside offers.

Recommended installation Process MH

- (1) Install felt paper or shingle underlayment per manufacturer's instructions to roof edge.
- (2) Install drip edge
- (3) Roll out shingle starter flush with edge of drip edge making sure it is flat to the roof surface.
- (4) Install shingles per manufacturer's instructions

Comment: There are two primary reasons for installing this way in MH as opposed to installing the drip edge first and the felt/SUL second. (1) installing the drip edge over the felt/SUL allows the starter to bond to a surface that is tight to the roof. This is more important in MH where home deliveries travel at speeds that can exceed 100 MPH when head winds are added to transit speed. (2) Traditional starters do not offer water and wind penetration protection. By the above installation that penetration barrier is maximized as the underside bonds to the drip edge and felt/SUL.

Very truly yours,

A handwritten signature in black ink, appearing to read "Steve Foster". The signature is written in a cursive, flowing style.

Steve Foster
Vice President